




Instruction on how to setup and use the Lighting Passport Spectrometer

Which App the Lighting Passport Models Uses




For Essence Pro, the cost for the App is **200\$**

For Essence Pro, the cost for the App is **200\$**

Connecting your Lighting Passport to your Mobile Device


Step 1

Open the app and press the small Lighting Passport




Step 2

Turn On Your Spectrometer, You should see a Serial Number



Step 3


Press the serial number and wait until it is connected



Taking a Measurements


Step 1

Press the light bulb




Step 2

Press the light bulb in the middle to subtract the background light



Step 3

Press the big spectrometer to take a measurement



After taking a Measurement



This is the result page of your measurement

1: You will return to the Main page. (**doing so, you will lose your test result, it is not save automatically.**)

2: For saving your Measurement. (**see next page on how to save your measurement.**)

3: you can swipe or select witch result you want to see

4: you can take another measurement witch will be compile with the same test data. Where it says "1 result(s)" will change to "2 Result (s)" if you take another one

Saving a Measurement

When you save a measurement, you can add more information and picture.

1: Will take you back to your test result.

2: The Title of your measurement.

3: You can add up to 3 pictures

4: This is the information of the time and location of the Measurement, it also include if it was “Continuous” and if the Background lighting was subtracted. **(Cannot be changed)**

5: The Product Name

6: After you have enter all the information you wanted, you need to press this check mark button to save it **(Please note that if you just go back to the test results (Point #1) it will not save)**

